

QUICK-START GUIDE

VESTAX TYPHOON

serato




Installation and Setup

The Vestax Typhoon is a class compliant USB plug and play device for both Mac and Windows and does not require any further driver installation.

1. Download and install the latest version of Serato DJ from <http://serato.com/dj/downloads>
2. Connect your Vestax Typhoon to an available USB Port.
3. Open Serato DJ.

Serato DJ Activation

To find out how to activate Serato DJ by either starting your free 14 day trial, or purchasing a license for Serato DJ, [click here](#) for the most up to date information.




#	Vestax Typhoon Control	Function
1	MASTER OUT	RCA Master Output
2	TOUCH SENSOR LEVEL	Adjust level of touch sensitivity for the platters
3	ADAPTOR	To power Typhoon with optional DC adaptor
4	POWER SOURCE	Select between Adaptor, Off and USB
5	USB	For connecting the Typhoon to your computer
6	MIC IN	Microphone Input Socket.
7	MIC LEVEL	Hardware microphone input gain control
8	PHONES LEVEL	Adjust the volume of the headphone output
9	PHONES	6.5mm jack for headphone output

NOTE: The mic level can be further adjusted in the Serato DJ setup screen under the MIXER tab.

serato



Controller



NOTE: SHIFT button is used with other buttons that have shift modifier functions

	Numark N4 Control	Function	SHIFT Function
1	PLAY/PAUSE	Play/Pause track	Stutter Play
2	PLATTER	Touch the top to scratch or jog. Moving the outside of the wheel will jog.	
3	+	Pitch bend up	
4	-	Pitch bend down	
5	SYNC	Sync On	
6	TEMPO FADER	Adjust Tempo	
7	DRY/WET (FX1/2)	Adjust FX UNIT 1/2 Slot 1 FX Parameter	
8	EQ	Adjust the High, Mid and Low Frequencies for each channel	
9	NAVIGATION	Library Scroll Up/Down or LOAD 1/2 to load track to selected deck (Tap twice for Instant Double)	
10	SONG LIST	Toggle open panels	
11	SHIFT	The SHIFT button is used with other buttons that have shift modifier functions	
12	FX 1/2	FX UNIT 1/2 Slot 1 Effect On/Off	
13	GAIN	Adjust gain for selected channel	
14	LED METER	Monitors the audio levels of the Master Output	
15	OUTPUT	Adjust Master Output	
16	LOOP SET	Auto Loop On/Off	
17	LOOP -	Halve Loop Length	
18	LOOP +	Double Loop Length	
19	CUP	Stutter Play	Load Next Track
20	CUE	Add/Trigger temporary cue	Jump to start of track (more than 2 Sec elapsed) Previous track (less than 2 sec elapsed)

21	FILTER	Activate platter filter mode. The Platter now acts as a combo filter.
22	CHANNEL FADER	Adjust Channel Volume
23	CROSSFADER	Fade between the two channels
24	CUE	Cue selected channel

NOTE: When using the CUE function, you can adjust the CUE MIX between the cue output and the master output. This is done by using CUE MIX found in the SETUP screen under the MIXER tab.

NOTE: Due to Vestax Typhoon mapping limitations, there is no Sync Off functionality. To turn Sync Off, click the OFF button on screen in Serato DJ


Looping

You have the choice of Auto or Manual Looping within Serato DJ with the Pioneer DDJ-S1.



NOTE You can also save a loop to the next available free loop slot in the software. To do this, click **+** on an available loop slot. Your loops are saved to the file and recalled the next time it is loaded. They are not lost if the file is moved or renamed.

Typhoon Control	Function
LOOP SET	Auto Loop On/Off
LOOP -	Halve Loop Length
LOOP +	Double Loop Length

DJ-FX

The DJ-FX in Serato DJ are powered by iZotope™. Click the FX tab  to open the FX panel. Select either 1, 2 or M to assign the selected effect bank to a deck or Master Output.

There are two available modes in the DJ-FX. Single FX Mode allows you to select one effect per FX bank, and has multiple parameters that can be adjusted. Multi FX Mode allows you to select up to three effects per FX bank, and adjust only one parameter, the FX Depth. The same effects available in Single FX mode are available in Multi FX mode, as well some additional presets.

You can select between the two FX modes by clicking either the Single FX mode button  or Multi FX mode button 

Typhoon Control	Single FX Mode	Multi FX Mode
FX 1 (button)	FX UNIT 1 Effect On/Off	FX UNIT 1 Slot 1 Effect On/Off
DRY/WET (FX 1)	Adjust FX Parameter 1	Adjust Slot 1 FX Parameter
FX 2 (button)	FX UNIT 2 Effect On/Off	FX UNIT 2 Slot 1 Effect On/Off
DRY/WET (FX 2)	Adjust FX Parameter 1	Adjust Slot 1 FX Parameter

Serato Video

Serato Video is a software plugin for Serato Software which adds the ability to playback and mix video files, use effects and fader transitions with your Serato DJ Controller, an additional MIDI controller or your mouse/keyboard.

For more information on Serato Video go to <http://serato.com/video>

MIDI

The MIDI feature in Serato DJ provides the ability to remap Serato DJ software functions to your primary Serato DJ controller, interface or mixer. You can also assign controls to a secondary MIDI controller to further enhance your performance.

[For more information on MIDI mapping with Serato DJ click here.](#)

To remap your supported Serato DJ device, open the **SETUP** screen and click the **MIDI** tab. If your Serato DJ device supports hardware remapping it will show up in the **MIDI Devices** list at the top.

Select your connected device from the MIDI Devices list and make sure the "Allow Serato Hardware Remapping" option is checked.

Allow Serato Hardware Remapping

Once checked, the MIDI assign button at the top of the screen will become available for you to start remapping.


MIDI


You can save, edit or delete MIDI presets in the **MIDI** tab of the **SETUP** screen. Clicking '**Restore Defaults**' will erase any custom mappings for all connected devices and revert their functions back to default.

[Download the Serato DJ software manual for further information.](#)

NOTE: Official Serato Accessories do not currently support user remapping. Hardware features that cannot be remapped at this stage are Jogwheels/Platters, Input Switches, Shift buttons and Performance Pad Mode buttons. Re-mapping any pad(s) in Hot Cue mode will also re-map the same pad in Saved Flip mode and vice versa.

Using the Tool Tips

Click on the  icon to enable Tool Tips. This is located in between the MIDI and setup button in the top right hand corner of the screen. Tool Tips provide a handy way to learn the various features of Serato DJ.

Move the mouse over a section of the screen to bring up a context sensitive tool tip. Holding the mouse over the  button with Tool Tips turned on will show you a list of all keyboard shortcuts.

For more information about how to use Serato DJ, please go to our website www.serato.com or refer to the Serato DJ Software Manual. For more information on your controller, please refer to the hardware manual.

For further help, please contact support@serato.com or go to www.serato.com/dj/support

serato

