

# QUICK-START GUIDE

## Pioneer CDJ-850

serato



# Installation and Setup

The Pioneer CDJ-850 is a class compliant USB plug and play device for Mac, but requires drivers for Windows. You will find these on the installation CD that is provided with your CDJ-850, or as a download from the [Pioneer website](#).

To use a pair of CDJs with Serato DJ, you will need at least 3 available USB ports. If you don't have 3 ports available you may be able to connect your CDJs to a powered USB hub. It is however, important to always connect your Serato DJ hardware directly to your computer.

Please also ensure you have also installed the latest available version of [Serato DJ](#).


1. Connect your Serato DJ hardware as per normal into an available USB port on your computer.
2. Connect the CDJ to your computer via USB cable or USB hub.
3. Open Serato DJ.
4. Press the PC button on the CDJ-850.
5. Press the Scroll Knob to connect to the computer.
6. Use the Scroll Knob to choose which virtual deck you wish the CDJ-850 to control.
7. Set the virtual deck in Serato DJ to Internal mode (INT).

Your CDJ-850 can also be used to play regular CDs. To do this just connect the CDJs audio outs (RCA) to your Serato DJ hardware as you would your regular CD players

serato



# Controller



#	Pioneer CDJ-850	Function
1	TIME MODE/AUTO CUE	Toggle between time elapsed/remaining on the CDJ screen
2	RELOOP EXIT	Reloop/Exit Loop (Loop Active)
3	BROWSE	Not Mapped
4	TAG LIST	Not Mapped
5	DISPLAY SCREEN	Displays library/crate information, track time and BPM etc
6	INFO	Not Mapped
7	MENU/UTLITY	Not Mapped
8	BROWSE/NAVIGATION	Scrolls through crates & library area / Push the scroll knob to move the cursor to library from crates / Push to load track
9	BACK	Toggles between Library and Crates
10	TAG TRACK/REMOVE	Add selected track to Prepare panel
11	EJECT	Eject a track from the selected virtual deck
12	CUE/LOOP	Select saved loop slot
13	MEMORY	Not Mapped
14	VINYL SPEED ADJUST	Turn to adjust start & stop time
15	DELETE	Delete selected saved loop
16	VINYL/JOG MODE	Toggles between jog or scratch mode for jog wheel
17	TEMPO RANGE	Cycle through available tempo ranges
18	MASTER TEMPO	Toggles between keylock On/Off
19	PITCH TEMPO SLIDER	Adjust Tempo
20	PLATTER	Touch the top to scratch or jog. Moving the outside of the wheel will jog
21	PLAY/PAUSE	Play/Pause track
22	CUE	Works as CDJ style cue button for setting and jumping to temporary cue
23	SEARCH	Fast Forward/Rewind

#	Pioneer CDJ-850	Function
24	TRACK SEARCH	Load Next Track/Previous Track
25	DIRECTION	Changes track play direction
26	LOOP OUT	Sets loop out point. (Press again to adjust the loop out point.)
27	BEAT SELECT	Changes loop range for AUTO BEAT LOOP buttons
28	LOOP IN	Set loop in point. (Press again to adjust the loop in point.)
29	AUTO BEAT LOOP	Each button will activate an auto loop of different length
30	DISC	Press DISC to play via CD
31	USB STOP	Not Mapped
32	USB	Press USB to play via USB source
33	PC	Press PC to play via HID mode


## MIDI


The MIDI control feature in Serato DJ provides the ability to map Serato DJ software functions to MIDI controller functions such as keyboards, triggers, sliders, and knobs. Integrating MIDI controllers into your Serato DJ setup can improve live performance usability, such as hitting pads on a MIDI controller to trigger Loops or Cue Points. Buttons marked as 'MIDI mappable' can be MIDI mapped the the Serato DJ function of your choice.

For further information on how to MIDI map Serato DJ software functions, download the Serato DJ manual.

**NOTE :** You can not change the functionality of other buttons by using the MIDI control feature.

## Using the Tool Tips

Click on the  icon to enable Tool Tips. This is located in between the MIDI and setup button in the top right hand corner of the screen. Tool Tips provide a handy way to learn the various features of Serato DJ.

Move the mouse over a section of the screen to bring up a context sensitive tool tip. Holding the mouse over the  button with Tool Tips turned on will show you a list of all keyboard shortcuts.

For more information about how to use Serato DJ, please go to our website [www.serato.com](http://www.serato.com) or download the Serato DJ Manual.

For more information on your CDJ-850, please refer to the Pioneer CDJ-850 manual.

For further help, please contact [support@serato.com](mailto:support@serato.com) or go to <http://serato.com/dj/support>

serato

